

PG-FLEX

TECHNICAL PRACTICE



8 CHANNEL LOOP START/GROUND START POTS CENTRAL TERMINAL CHANNEL UNIT

Model	List	CLEI Code
FLC-704	4B	N/A

Revision History of This Practice

Revision	Release Date	Revisions Made
01	October 22, 1999	Initial Release
02	January 10, 2002	Release to rebrand document to comply with ADC standards
03	January 6, 2003	Updated Product Support Information

©Copyright 2003 ADC DSL Systems, Inc. All Rights Reserved.

ADC is a registered trademark of ADC Technologies, Inc. PG-Flex is a registered trademark of ADC DSL Systems, Inc. No right, license, or interest to such trademarks is granted hereunder, and you agree that you shall assert no such right, license, or interest with respect to such trademarks. Other product names mentioned in this document are used for identification purposes only and may be trademarks or registered trademarks of their respective companies.

Information contained in this document is company private to ADC DSL Systems, Inc., and shall not be modified, used, copied, reproduced or disclosed in whole or in part without the written consent of ADC.

Contents herein are current as of the date of publication. ADC reserves the right to change specifications at any time without notice. Information furnished by ADC is believed to be accurate and reliable. In no event shall ADC be liable for any damages resulting from the loss of data, loss of use, or loss of profits and ADC further disclaims any and all liability for indirect, incidental, special, consequential or other similar damages. This disclaimer of liability applies to all products, publications and services during and after the warranty period.

USING THIS PRACTICE

Three types of messages, identified by icons, appear in the text.



Notes indicate information about special circumstances.



Cautions indicate the possibility of equipment damage or the possibility of personal injury.



Electrostatic Discharge (ESD) susceptibility symbols indicate that a device or assembly is susceptible to damage from electrostatic discharge. You must wear an antistatic wrist strap connected to the appropriate ground connection prior to performing installation procedures. You must also observe normal ESD precautions when handling electronic equipment. Do not hold electronic plugs by their edges. Do not touch components or circuitry.

INSPECTING YOUR SHIPMENT

Upon receipt of the equipment:

- Unpack each container and visually inspect the contents for signs of damage. If the equipment has been damaged in transit, immediately report the extent of damage to the transportation company and to ADC. Order replacement equipment, if necessary.
- Check the packing list to ensure complete and accurate shipment of each listed item. If the shipment is short or irregular, contact ADC as described in [“Returns” on page 11](#). If you must store the equipment for a prolonged period, store the equipment in its original container.

TABLE OF CONTENTS

Overview	1
Description	1
Front Panel	2
Specifications	3
Operational Capabilities	4
Circuit Operation.....	4
Loop Start Operation	4
On-hook (Idle) Condition.....	4
Subscriber Initiated Outgoing Call.....	5
Subscriber Receives Incoming Call	5
Busy Condition.....	5
Ground Start Operation	6
Idle Condition.....	6
Subscriber Initiates Outgoing Call	6
Subscriber Receives Incoming Call	8
Busy Condition.....	8
CLASS Features	8
Forward Disconnect.....	8
Installation and Turn-up	9
Installing.....	9
Provisioning	9
Verify Installation	9
Troubleshooting	10
Product Support	11
Technical Support	11
Limited Warranty.....	11
Returns	11
FCC Class A Compliance	13
Modifications	13
Acronyms	14

LIST OF FIGURES

1. FLC-704 Front Panel.....	2
-----------------------------	---

LIST OF TABLES

1. FLC-704 Front Panel LEDs and Labels	2
2. Circuit Interactions for an Idle Condition (Loop Start).....	4
3. Circuit Interactions When a Subscriber Initiates an Outgoing Call (Loop Start).....	5
4. Circuit Interactions When a Subscriber Receives an Incoming Call (Loop Start).....	5
5. Circuit Interactions for a Busy Condition (Loop Start).....	6
6. Circuit Interactions for an Idle Condition (Ground Start).....	6
7. Circuit Conditions When a Subscriber Initiates an Outgoing Call (Ground Start).....	6
8. Circuit Conditions When a Subscriber Receives an Incoming Call (Ground Start)	8
9. Circuit Conditions for a Busy Condition (Ground Start)	8
10. FLC-704 CU Troubleshooting	10

OVERVIEW

The ADC® PG-Flex® FLC-704 List 4B provides eight loop start or ground start channel interfaces for POTS between a PG-Flex COT Shelf and the Central Office (CO) switch using A-Law pulse code modulation (PCM) encoding. In addition, the FLC-704 provides metallic access to the subscriber line connection through an optional metallic bypass pair for subscriber circuit testing.

DESCRIPTION

Features of the PG-Flex FLC-704 are:

- eight LS/GS POTS subscriber interfaces
- 64 kbps A-Law PCM encoding
- meter tones (12 kHz, 16 kHz)
- front panel ACTIVE LEDs indicate on-hook (idle), ringing, metallic access, and off-hook condition for each channel
- front panel FAULT LED indicator simplifies troubleshooting
- Pair Gain Test Controller (PGTC) compatibility
- Custom Local Area Signaling Services (CLASS) support (such as, caller ID)
- line-side answer supervision support (reverse battery)
- forward disconnect
- distinctive ringing
- metallic access for subscriber circuit testing
- repeat of loop off-hook, ground start seizure, and Ring-Trip conditions to the CO switch

FRONT PANEL

The FLC-704 front panel (Figure 1) includes green status LEDs for each line indicating on-hook (idle), ringing, and off-hook conditions, as well as a red LED indicating a fault condition on the CU. Table 1 lists the different states and indications for the FLC-704 CU front panel LEDs.




Figure 1. FLC-704 Front Panel

Table 1. FLC-704 Front Panel LEDs and Labels

LED and Label	Function
ACTIVE (1 through 8)	Solid green: Channel is off-hook. Fast flashing green: Channel is in test access mode. Slow flashing green: LED follows the ring signal. Off: Channel is on-hook (idle).
FAULT	Red: Fault detected by the unit. Refer to Table 10 on page 10 for troubleshooting procedures. Off: No faults detected.
Warranty Control Number Label	Indicates the beginning year and month of the equipment warranty. Also indicates the unit revision number. For example, a warranty control number of 71203 indicates a warranty beginning 1997 (7), in December (12), and the revision is 03.
Bar Code Label	Contains the serial number and part number of the equipment in both bar code and text formats.

SPECIFICATIONS

Electrical Characteristics

Analog Impedance	600 Ω	
Loop Resistance	100 Ω , (CO switch to COT) maximum	
End-to-End Loss	-2.5 dB \pm 1.0 dB at 100 Hz	
Ring-Ground Resistance	500 Ω	
Channel Signature	<u>Loop Start Lines</u>	<u>Ground Start Lines</u>
Tip-Ring	(open)	23.75 k Ω , 1%
Tip-Ground	162 k Ω , 1%	162 k Ω , 1%
Ring-Ground	226 k Ω , 1%	226 k Ω , 1%

Environmental

Operating Elevation	-200 ft. to 13,000 ft. (-60 m to 4000 m)
Temperature	-40° F to +150° F (-40° C to +65° C)
Humidity	5% to 95% (noncondensing)

Physical

Weight	0.8 lb. (0.4 kg.)
Height	6.75 in. (17.1 cm.)
Width	1.0 in. (2.5 cm.)
Depth	10.5 in. (26.7 cm.)

OPERATIONAL CAPABILITIES

The FLC-704 List 1A CU provides eight loop start or ground start POTS interfaces to the CO switch. The unit performs the interface function between the analog POTS circuit and the internal digital pulse coded modulation (PCM) bus. In addition, each CU:

- detects forward battery
- detects ringing voltage
- detects reverse battery
- detects Tip ground and Tip open
- detects 12 kHz or 16 kHz meter tone
- detects a subscriber test access signal
- provides loop closure
- provides grounded ring lead
- converts analog signals to and from 64 kbps A-Law PCM digital format

CIRCUIT OPERATION

The following paragraphs define the FLC-704 circuit operation when using loop start for subscriber lines or ground start for PBX lines. Each FLC-704 circuit has an associated LED that indicates when the line is off-hook, on-hook (idle), ringing, or under test (see [Table 1 on page 2](#) for front panel LED definitions).

Loop Start Operation

The following section summarizes the loop start sequences for on-hook (idle), subscriber initiated outgoing calls, subscriber received incoming calls, and busy conditions.

On-hook (Idle) Condition

Loop start idle condition is a Ring-lead negative and Tip-lead positive from the CO with the same condition out of the RT toward the subscriber (see [Table 2](#) for circuit interactions).

Table 2. Circuit Interactions for an Idle Condition (Loop Start)

Operation	CO Switch	FLC-704 COCU	FRC-754 RTCU	Subscriber
Circuit Idle	No ringing	⇒	No ringing	⇒
	⇐	On-hook	⇐	On-hook

Subscriber Initiated Outgoing Call

The following occurs when the calling line goes off-hook (see [Table 3 on page 5](#) for circuit interactions):

- loop current flows and is detected by the FLC-704 CU
- FLC-704 receives an off-hook signal from the RT
- FLC-704 generates an off-hook condition to the CO switch
- CO sends dial tone
- FRC-754 passes a dial pulse or Dual Tone Multi Frequency (DTMF) signal through the FLC-704 from the subscriber and forwards these to the CO.

Table 3. *Circuit Interactions When a Subscriber Initiates an Outgoing Call (Loop Start)*

Operation	CO Switch	FLC-704 COCU	FRC-754 RTCU	Subscriber
CO Idle	No ringing	⇒	No ringing	⇒
Subscriber goes off-hook	⇐	Off-hook	⇐	Off-hook
CO returns dialtone	Dialtone	⇒	Dialtone	⇒
Subscriber Dials	⇐	DP or DTMF	⇐	DP or DTMF

Subscriber Receives Incoming Call

The following occurs for an incoming call (see [Table 4](#) for circuit interactions):

- FLC-704 detects a ringing signal from the CO
- FLC-704 signals the FRC-754 which then connects ringing to the subscriber
- subscriber line goes off-hook and the FRC-754, through the FLC-704, provides an off-hook condition to the CO switch

Table 4. *Circuit Interactions When a Subscriber Receives an Incoming Call (Loop Start)*

Operation	CO Switch	FLC-704 COCU	FRC-754 RTCU	Subscriber
Subscriber Idle	⇐	On-hook	⇐	On-hook
CO generates ringing	Ringing	⇒	Ringing	⇒
Subscriber goes off-hook	⇐	Off-hook	⇐	Off-hook
Ring trip	No ringing	⇒	No ringing	⇒

Busy Condition

Loop start busy condition at the RT is a Ring lead negative and a Tip lead positive with loop current flowing. The same conditions occurs at the CO (see [Table 5](#) for circuit interactions).

Table 5. *Circuit Interactions for a Busy Condition (Loop Start)*

Operation	CO Switch	FLC-704 COCU	FRC-754 RTCU	Subscriber
Circuit busy	No ringing	⇒	No ringing	⇒
	←	Off-hook	←	Off-hook

Ground Start Operation

The following section summarizes the ground start sequences for on-hook (idle), subscriber initiated outgoing calls, subscriber received incoming calls, and busy conditions.

Idle Condition

Ground start idle condition is a Tip-lead open and Ring-lead negative from the CO and Tip lead open and Ring-lead negative at the RT (see [Table 6](#) for circuit interactions).

Table 6. *Circuit Interactions for an Idle Condition (Ground Start)*

Operation	CO Switch	FLC-704 COCU	FRC-754 RTCU	Subscriber
Circuit Idle	Tip - no ground No ringing	⇒	Tip - no ground No ringing	⇒
	←	Ring - no ground On-hook	←	Ring - no ground On-hook

Subscriber Initiates Outgoing Call

The following occurs when a PBX requests service for an outgoing call (see [Table 7](#) for circuit interactions):

- PBX grounds Ring lead at the RT
- FRC-754 signals the FLC-704
- FLC-704 operates a Ring-ground relay that requests dial tone from the CO (this makes the circuit busy, or seizes it, for outgoing calls, and blocks any incoming calls prior to the PBX dialing (that is, it prevents glare where incoming and outgoing calls may occur simultaneously on the same line). Glare occurs when both ends of a telephone line or trunk are seized at the same time.
- CO sends dial tone and grounds the Tip to signal the PBX to begin dialing
- FLC-704 detects Tip-ground, closes the loop between Tip and Ring, and signals the FRC-754 to send Tip ground to the PBX
- PBX removes the original Ring-ground condition and completes the loop (Tip and Ring)

Table 7. *Circuit Conditions When a Subscriber Initiates an Outgoing Call (Ground Start)*

Operation	CO Switch	FLC-704 COCU	FRC-754 RTCU	Subscriber
CO Idle	Tip - No ground No ringing	⇒	Tip - No ground No ringing	⇒

Table 7. *Circuit Conditions When a Subscriber Initiates an Outgoing Call (Ground Start)*

Operation	CO Switch	FLC-704 COCU	FRC-754 RTCU	Subscriber
Subscriber requests dialtone	←	Ring - ground On-hook	←	Ring - ground On-hook
CO returns dialtone	Tip - ground Dialtone	⇒	Tip - ground Dialtone	⇒
Subscriber Dials	←	Ring - no ground Off-hook DP or DTMF	←	Ring - no ground Off-hook DP or DTMF

Subscriber Receives Incoming Call

The following occurs for an incoming call (see [Table 8](#) for interactions):

- FLC-704 detects a ringing signal from the CO, along with Tip-ground
- FLC-704 signals the FRC-754 to connect Tip-ground and ringing to the PBX
- PBX goes off-hook and the FRC-754, through the FLC-704, closes the loop between Tip and Ring, the CO disconnects ringing and establishes an audio path.

Table 8. *Circuit Conditions When a Subscriber Receives an Incoming Call (Ground Start)*

Operation	CO Switch	FLC-704 COCU	FRC-754 RTCU	Subscriber
Subscriber Idle	←	Ring - no ground On-hook	←	Ring - no ground On-hook
CO seizes loop	Tip - ground No Ringing	⇒	Tip - ground No Ringing	⇒
CO generates ringing	Tip -ground Ringing	⇒	Tip -ground Ringing	⇒
Subscriber goes off-hook	←	Ring - no ground Off-hook	←	Ring - no ground Off-hook
Ring trip	Tip - ground No ringing	⇒	Tip - ground No ringing	⇒

Busy Condition

Ground start busy condition at the RT is a Ring lead negative and a Tip lead positive with loop current flowing. The same conditions occurs at the CO (see [Table 9](#) for circuit interactions).

Table 9. *Circuit Conditions for a Busy Condition (Ground Start)*

Operation	CO Switch	FLC-704 COCU	FRL-754 RTCU	Subscriber
Circuit busy	Tip - ground No ringing	⇒	Tip - ground No ringing	⇒
	←	Ring - no ground Off-hook	←	Ring - no ground Off-hook

CLASS Features

PG-Flex supports on-hook transmission of analog signals. When Call ID (a CLASS feature) is activated, the CO generates analog signalling toward the PBX between the first and second bursts of the ringing signal.

Forward Disconnect

The forward-disconnect function releases a called line that was left on hold or an answering set that requires a loop open to be able to turn off.

INSTALLATION AND TURN-UP

INSTALLING

- 1 Insert each FLC-704 CU into the COT Shelf and observe that all LEDs:
 - turn ON for approximately 2 seconds
 - scan from top to bottom
 - flash all ON, then OFF

If the LEDs do not follow the above sequence, see [Table 10](#).

- 2 Verify that the front panel indicators ACTIVE 1 through ACTIVE 8 and FAULT LEDs are all off when the PG-Flex system has powered up, established HDSL synchronized communications, and no calls are in progress.



To activate the ground start feature, use a List 3 of higher PG-Flex CO and RTLUs.

PROVISIONING

Provision the FLC-704 using the appropriate line unit technical practice. For each channel provisioned, select loop start or ground start.

VERIFY INSTALLATION

After the PG-Flex system is powered up and HDSL communication is synchronized:

- 1 Verify that the front panel ACTIVE indicators are all OFF and the FAULT indicator is OFF (no calls are in progress).
- 2 Test the loop start circuits, as follows:
 - Place an outgoing call for each subscriber circuit provisioned, and verify that the ACTIVE LED tracks the progress of the call (refer to [Table 1 on page 2](#) for front panel indications).
 - Place an incoming call to each subscriber circuit provisioned, and verify that the ACTIVE LED tracks the progress of the call (refer to [Table 1 on page 2](#) for front panel indications).
- 3 Test the ground start circuits, as follows:
 - Place an outgoing call for each subscriber circuit provisioned, and verify that the ACTIVE LED tracks the progress of the call (refer to [Table 1 on page 2](#) for front panel indications).
 - Place an incoming call to each subscriber circuit provisioned, and verify that the ACTIVE LED tracks the progress of the call (refer to [Table 1 on page 2](#) for front panel indications).

TROUBLESHOOTING

Table 10. *FLC-704 CU Troubleshooting*

Indication	Problem	Action
FAULT LED On	The FLC-704 processor has detected a fault.	Remove and reinsert the CU. If the FAULT LED does not extinguish, replace the CU.
Troubleshooting based on customer-originated trouble reports		
No Dial tone, Can not Dial	<ul style="list-style-type: none"> faulty RT or COT CU facility short/open CO switch problem Tip/Ring reversed at CO 	<ol style="list-style-type: none"> Lift the subscriber pair at the network interface. If dial tone is present and you can place a call, refer the problem to the customer per local practice. If you can not hear a dial tone or can not place a call at the network interface (with the subscriber pair lifted), check for dial tone at the RT. If a dial tone is present, check the pair between the RT and the network interface. If no dial tone is present, replace the RT CU. If the problem still exists, re-insert the original RT CU and replace the COT CU. Test for operation. If the problem still exists, refer the problem to the CO switch.
Phone Does not Ring	<ul style="list-style-type: none"> high-resistance subscriber line short faulty RT or CO CU loop length too long 	<ol style="list-style-type: none"> Lift the subscriber pair at the network interface. If ringing is present, refer the problem to the customer per local practice. If ringing is not present, check for ringing at the RT. If ringing is present, check the pair between the RT and the network interface. If no ringing is present, replace the RT CU. If ringing is still not present, check a circuit on another CU. If ringing is still not present, replace the LU. If ringing is still not present at the RT, re-insert the original CU and LU. Test for ringing at the COT. Test for ringing into the COT from the CO switch. If no ringing is present, refer the trouble to the CO switch. If ringing is present, replace the COT CU. Test again for ringing at the network interface. If ringing is still not present, contact ADC technical assistance per Product Support. Verify the resistance of the copper loop between the RT Enclosure and the network interface is less than 530 Ω.
Phone does not stop ringing	<ul style="list-style-type: none"> faulty subscriber instrument faulty RT CU loop length too long 	<ol style="list-style-type: none"> Test for ring trip at the network interface. If the ringing is tripped, refer the trouble to the customer per local practice. If the ringing is not tripped, test for tripping at the RT. If ring trip does occur, check the loop for excessive length. If ring trip does not occur, replace the RT CCU. If ring trip still does not occur, contact ADC technical assistance per Product Support. Verify the resistance of the copper loop between the RT Enclosure and the network interface is less than 530 Ω.
Can not Hear, Can not Be Heard	<ul style="list-style-type: none"> subscriber problem faulty RT or COT CU 	<ol style="list-style-type: none"> Lift the subscriber line at the network interface and check the signal level. If correct, refer trouble to the customer per local practice. If the level is too low, check the level at the RT. If the level is correct at the RT, check the pair between the RT and the network interface. If the level is too low at the RT, replace the RT CU. If the level is still too low, re-insert the original RT CU. Check the level at the COT coming from the CO switch. If it is correct, replace the COT CU. If it is not correct, refer the problem to the CO regarding the switch. If the level is still not correct, re-insert the original COT CU. Contact ADC technical assistance per Product Support.

PRODUCT SUPPORT

TECHNICAL SUPPORT

Technical Assistance is available 24 hours a day, 7 days a week by the contacting Customer Service Engineering group at:

Telephone: 800.366.3891
The 800 telephone support line is toll-free in the U.S. and Canada.

Email: wsd_support@adc.com

Knowledge Base: http://adc.com/Knowledge_Base/index.jsp

Web: www.adc.com

LIMITED WARRANTY

Product warranty is determined by your service agreement. Refer to the ADC Warranty/Software Handbook for additional information, or contact your sales representative or Customer Service for details.

RETURNS

To return equipment to ADC:

- 1 Locate the number of the purchase order under which the equipment was purchased. To obtain a return authorization number, you need to provide the original purchase order number to ADC's Return Material Authorization (RMA) Department.
- 2 Call or write ADC's RMA Department to ask for an RMA number and any additional instructions. Use the telephone number, fax number or email address listed below:
 - Telephone: 800.366.3891
 - Email Address: rma@ADC.com
- 3 Include the following information, in writing, along with the equipment you are returning:
 - Company name and address.
 - Contact name and telephone number.
 - The shipping address to which ADC should return the repaired equipment.
 - The original purchase order number.
 - A description of the equipment that includes the model and part number of each unit being returned, as well as the number of units that you are returning.
 - The reason for the return. For example:
 - The equipment needs an ECO/ECN upgrade.
 - The equipment is defective.



If the equipment is defective, please tell us what you observed just before the equipment malfunctioned. Be as detailed in your description as possible.

If there is another reason for returning the equipment, please let us know so we can determine how best to help you.

- 4 Pack the equipment in a shipping carton.
- 5 Write ADC's address and the RMA Number you received from the RMA Department clearly on the outside of the carton and return to:

ADC DSL Systems, Inc.
14352 Franklin Ave.
Tustin, CA 92780-7013

Attention: **RMA (Number)**



All shipments are to be returned prepaid. ADC will not accept any collect shipments.

FCC CLASS A COMPLIANCE

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Modifications

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by ADC Technologies, Inc. voids the user's warranty.

All wiring external to the product(s) should follow the provisions of the current edition of the National Electrical Code.

ACRONYMS

2B1Q	2 binary bits encoded in one quaternary symbol
AWG	American Wire Gauge
CLASS	Custom Local Area Signaling Services
CO	Central Office
COT	Central Office Terminal
DS0	Digital Signal Level Zero (64 kb/s)
DTMF	Dual Tone Multi Frequency
HDSL	High-bit-rate Digital Subscriber Line
kbps	KiloBits Per Second
MLT	Mechanized Loop Testing
PBX	Private Branch Exchange
PCM	Pulse Code Modulation
PGTC	Pair Gain Test Controller
POTS	Plain Old Telephone Service
RMA	Return Material Authorization
RT	Remote Terminal
RTL	Remote Terminal Line Unit

World Headquarters:

ADC Telecommunications, Inc.
12501 Whitewater Drive
Minnetonka, Minnesota USA 55343

For Technical Assistance:

800.366.3891



1251760
